



**INSTALLATION INSTRUCTIONS**  
**PART No. 30594 HOOD PROP ROD**  
**MODEL No.**



Lift the hood up and support the hood using a piece of wood (2" x 4") x 3 Ft long or something comparable.

Using a .75" drill bit, drill down thru the head of the rivet holding the factory prop rod in place. See photo 1 and photo 2.

With the head of the rivet removed use a drift pin to knock the remaining rivet thru the steel bracket.

Tap the hole with a 5/16"-18 NC tap.

Position the new Stainless Steel prop rod in place (see photo 3) and secure using the 5/16" bolt and flat washer provided.



**INSTALLATION INSTRUCTIONS**  
**PART No. 30594 HOOD PROP ROD**  
**MODEL No.**



Lift the hood up and support the hood using a piece of wood (2" x 4") x 3 Ft long or something comparable.

Using a .75" drill bit, drill down thru the head of the rivet holding the factory prop rod in place. See photo 1 and photo 2.

With the head of the rivet removed use a drift pin to knock the remaining rivet thru the steel bracket.

Tap the hole with a 5/16"-18 NC tap.

Position the new Stainless Steel prop rod in place (see photo 3) and secure using the 5/16" bolt and flat washer provided.